

Eris[®] HD10BT

Professional Headphones with Active Noise
Canceling and Bluetooth[®] wireless technology

Owner's Manual



Table of Contents

1 Overview — 1

- 1.1 Introduction — 1
- 1.2. What is in the box — 1
- 1.3. Companion PreSonus Products — 2

2. Hookup — 3

- 2.1. Right Earpiece Connections and Controls — 3
 - 2.1.1. Bluetooth Pairing and Powering — 3
 - 2.1.2. Track Navigation and Bluetooth volume — 3
 - 2.1.3. Phone Call Controls — 4
 - 2.1.4. Hardwiring — 5
- 2.2. Left Earpiece Connections and Controls — 5
 - 2.2.1. Active Noise Canceling (ANC) — 5
 - 2.2.2. Charging — 5

1 Overview

1.1 Introduction



Thank you for purchasing the PreSonus® Eris™ HD10BT professional headphones with Active Noise Canceling and Bluetooth wireless technology. PreSonus® Eris HD10BT headphones provide studio-quality audio performance with the mobility and freedom of Bluetooth connectivity. Active Noise Canceling (ANC) reduces ambient sounds by up to 18 dB – so whether you're walking down a busy street, or sitting in the middle seat on an airplane, you can listen to your favorite music, podcasts, or binge-worthy TV series in vivid sonic fidelity.


PreSonus Audio Electronics is committed to constant product improvement, and we highly value our customers and their creative endeavors. We appreciate the support you have shown us by purchasing your Eris HD10BT headphones and are confident that you will enjoy it for years to come!

1.2. What is in the box

Your Eris HD10BT package contains the following:
PreSonus Eris HD10BT professional headphones




Quick Start Guide



1M 1/8" (3.5mm) TRS-TRS cable




1/8" (3.5mm) TRS-to-1/4" (6.35mm) TRS adapter



1M USB charging cable



Hardshell carrying case




PreSonus Health, Safety, and Compliance Guide for Headphones

1.3. Companion PreSonus Products

Thanks for choosing PreSonus! As a solutions company, we believe the best way to take care of our customers (that's you) is to ensure that you have the best possible experience from the beginning of your signal chain to the end. To achieve this goal, we've prioritized seamless integration throughout every design phase of these products from day one. The result is systems that communicate with each other as intended – straight from the box – without excessive configuration hassles.


We're here for you. Find out more at www.presonus.com



2. Hookup


2.1. Right Earpiece Connections and Controls

2.1.1. Bluetooth Pairing and Powering




To power on your Eris HD10BT headphones, press and hold the center button for 3 seconds, if no Bluetooth device is paired or the previously paired Bluetooth device is not available, your Eris HD10BT headphones will enter pairing mode.

While in pairing mode, the LED on the lower right of the earpiece will flash blue and red.




On your Bluetooth device, select "PreSonus HD10BT" from the pairing menu.



To power down your Eris HD10BT headphones, press and hold the center button for 5 seconds.

2.1.2. Track Navigation and Bluetooth volume

The following controls are available for use with your favorite Bluetooth device while listening to audio:




1. **Volume Up / Prev Track.** Press once to increase the Bluetooth playback volume. Press and hold to navigate to the previous track.
2. **Play/Pause.** Press this button to remotely start and stop playback on your Bluetooth device.
3. **Volume Down / Next Track.** Press once to lower the Bluetooth playback volume. Press and hold to advance to the next track.


2.1.3. Phone Call Controls

The center button can also be used to remotely answer or reject calls when your phone is paired via Bluetooth to your Eris HD10BT headphones:


Press once to answer a call.



Press and hold for 1 second to reject a call.




Press twice to redial the last number.




2.1.4. Hardwiring

Your Eris HD10BT headphones can be used wired when the battery is low, or if you would like to connect them a device that does not offer Bluetooth. The 1/8" TRS jack is located on the bottom of the Right Earpiece. Use the included cable or any standard 1/8" TRS cable.



2.2. Left Earpiece Connections and Controls

2.2.1. Active Noise Canceling (ANC)




On the bottom of the Left earpiece, you will find Active Noise Canceling (ANC) switch. Active Noise Canceling can be used independently from Bluetooth listening. However, ANC does require that your Eris HD10BT headphones be powered on.

Note: Using ANC will reduce your battery charge at a faster rate than simply using Bluetooth wireless.

When ANC is active, the adjacent LED will illuminate green.

2.2.2. Charging



Connect the included USB cable to the charging port to charge your Eris HD10BT headphones using either a standard USB outlet charger or a computer. The ANC LED will illuminate red while charging. When the battery is fully charged, the LED will turn off. Once charged, the Eris HD10BT headphones provide up to 8 hours of Bluetooth playtime with ANC active, and up to 16 hours ANC off.

Do not use Bluetooth while charging.

Added bonus: PreSonus' previously Top Secret recipe for . . .

Chicken and Andouille Gumbo

Ingredients:

- 1 C All-Purpose flour
- $\frac{3}{4}$ C Vegetable Oil
- 1 large onion (diced)
- 1 small onion (quartered)
- 6 celery stalks (diced)
- 1 large green bell pepper (diced)
- 3 cloves garlic (2 minced, 1 whole)
- 1 lb link Andouille sausage
- 4 Chicken leg quarters
- 4 qt water
- 4 bay leaves
- 1 tsp thyme
- 1 tsp Old Bay seasoning
- 1-2 C frozen okra, sliced
- $\frac{1}{4}$ C fresh parsley, minced
- 6-8 eggs (optional)

Cooking Instructions:

1. In a large pot, combine whole chicken leg quarters, water, quartered onion, Old Bay, 2 bay leaves and 1 whole clove garlic. Cover and bring to a low boil. Simmer stock until chicken is falling off the bone. Remove the chicken and set aside. Discard the onion, bay leaves, and garlic, reserving the liquid.
2. In a heavy saucepan, heat 1 Tbsp of the oil on medium high heat and brown the andouille until it is cooked through. Set aside sausage for later.
3. In the same saucepan, add and heat remaining oil. Slowly add flour 1-2 Tbsp at a time, stirring continuously. Continue cooking and stirring the roux until it is a dark brown (it should look like melted dark chocolate). Be careful to not to get the oil too hot or the flour will burn and you'll have to start over.
4. Once roux has reached the correct color, add diced onion, celery, green pepper, and minced garlic. Cook until vegetables are very tender. Do not cover.
5. Slowly add 1 quart of chicken broth and bring to a low boil, stirring constantly.
6. Transfer roux mixture to a soup pot and bring to low boil. Do not cover, the roux will settle on the bottom of the pot and burn.
7. Add remaining chicken broth, bay leaves, and thyme. Simmer for 30 minutes.
8. While gumbo is simmering, debone and shred chicken and slice the andouille.
9. Add chicken and andouille to gumbo and return to a simmer. Simmer for 30-45 minutes.
10. Stir in frozen okra and parsley and bring to a rolling boil.
11. **Optional:** Crack one egg into a teacup and quickly pour into the boiling gumbo. Repeat with the other eggs being careful not to cluster them too closely. After all the eggs have risen back to the surface, reduce heat and simmer.
12. Correct seasoning with salt and pepper (red, white and/or black) if necessary.
13. Serve over rice with potato salad.

Serves 12

Eris® HD10BT

Professional Headphones with Active Noise
Canceling and Bluetooth® wireless technology

Owner's Manual

